BOX RACK KIT

User and lnstallation Guide

TOOLS REQUIRED:

. Allen Key - 4 mm
. Allen Key - 5 mm (MY'13 and MYl4 motorcycles)
. T45 Torx Wrench (MYl5 motorcycles)

INCLUDED PARTS:

PART NUMBER OTY PART NAME
r 0-05950 1 Top Case Weldment Assembly
1 0-05956 1 Top Case Rubber Bumper
90-07273 2 Hexagon Sccket Buttcn Head Cap Screw - M6x1 6-8.8
90-07009 2 Hexagon Socket Button Head Dcg Point Screw - MBx50

INSTALLATION:

1 . On MY13 or MYl4 motorcycles, remove seat bolts using 5 mm allen key and remove the seat. Retain for re-use but if you happen to strip the heads, don't worry. We include two replacements, MBx50 Hexagon Socket Button Head Dog
Point Screws.

On MY15 and later motorcycles remove the seat bots using a T45 Torx wrench
and retaln for re-use, You won't need the extra M8x50 screws

2. Slide Top Case Rubber Bumper onto lower flange of the Top Case Weldment
Assembly.

lI you have any questions, please contact your dealer for proper usage or installation. 88-06521 o" on _Gl

3=ERg

lnstallation lnstructions